

SUPER CONTROL SC125

OPERATING INSTRUCTIONS

SETTING UP THE LINEWINDER **A** & **B**

- Place the linewinder on a solid table or surface with the foot control on the floor.
- Read the "Important Operational Information" label affixed to the base of the linewinder prior to operating the machine.
- Mount the bulk spool holder to the base.
- The bulk spool assembly has no mechanical braking mechanism, so any braking of the spool all must be done by hand. Wearing a glove is recommended.
- For optimum performance and to avoid risk of injury or damage to reels and spools, begin winding at slow or minimal speed.
- The linewinder can wind line on any spool, metal or plastic. However, spools can break as a result of being in poor condition. Triangle Sport is not responsible for these spools.
- The linewinder comes with an "over-ride" speed control which gives the operator the ability to restrict the top-end speed of the foot pedal control by adjusting the speed control dial located on the top of the unit.

STRIPPING LINE **C**

- Mount the stripper spool between the support arm and cone point assemblies with the line captured between the stripper and the cork face of the cone point assembly.
- Begin all stripping slowly and keep the line tension to a minimum when stripping line to allow for easy removal from the stripper spool.
- Slow the speed down when the reel or spool is reaching the end of the line.

FILLING SPINNING SPOOLS **D**

- Mount the spinning spool between the support arm and cone point assemblies.
- Determine the winding direction of the reel or spool and set the motor direction.
- Set up the bulk spool so the line comes off in the same direction that it winds onto the reel or spool to prevent line twist.
- The hand-held line guide should be used when filling spinning reel spools.

FILLING CONVENTIONAL REELS **E**

- Insert the T-Bar into the drive shaft and mount the reel seat to the bar by using the reel clamps. Check to see if the reel is centered by extending the T-Bar until it almost touches the reel. Raise or lower the reel bar assembly as necessary to achieve proper alignment.
- Once the reel is centered properly, tighten the reel to lock into position. **DO NOT OVERTIGHTEN. DAMAGE WILL OCCUR. See video on our website.**
- The motor should be set to rotate counterclockwise (FORWARD) for right-hand retrieve reels.
- For left-hand retrieve reels the hand-held line guide provided must be used and the motor direction set to rotate clockwise (REVERSE). A left hand winding attachment kit (SKU 2500) is also available as an option and can be purchased directly from the Triangle Sport website.

SERVICE AND WARRANTY POLICY

Limited Warranty

- Triangle Sport's obligation will be limited to 1-year from the date of shipment from the factory and will include repairing or replacing any part of the product which, upon our examination we determine to be defective. Such a warranty will not apply to defects that result from accidents, alterations, misuse, abuse or normal wear.

Service and Repair





- Spare and/or replacement parts for the linewinder may be ordered directly from the Triangle Sport website.
- Please retain the original shipping container should the entire unit need to be shipped back to the factory.
- You must obtain a Return Authorization Number before sending machine in for any warranty service.

www.trianglesport.com

25 Park Way, Upper Saddle River, NJ 07458

Technical Support: 888.656.6686 • Made in the USA

CONFIDENCE IN YOUR LINE. EVERY TIME.



TRIANGLESPORT
LINEWINDERS